



www.vcx.com.pl

KARTA KATALOGOWA

WESA LC 50 - RAMKA POCZWÓRNA



Ramka poczwórna – przeznaczona do montażu czterech gniazd i łączników w układzie pionowym i poziomym.


Oznaczenie i pakowanie

numer katalogowy	seria	nazwa produktu	opakowanie jednostkowe	kod EAN	opakowanie zbiorcze	kod EAN
LC 50	LC	RAMKA POCZWÓRNA	1 szt.	05906874479360	10 szt.	05906874479551

Informacje dotyczące bezpieczeństwa:

- Instalacja, konserwacja i ewentualna wymiana tego urządzenia musi być wykonywana wyłącznie przez wykwalifikowaną i uprawnioną osobę.
- Należy zastosować się do wszystkich odnośnych lokalnych, regionalnych i krajowych regulacji podczas instalacji, używania, konserwacji oraz wymiany urządzenia.
- Otwarcie lub jakakolwiek inna ingerencja w urządzenie powoduje utratę gwarancji.
- Obciążenia przekraczające wartości podane od Producenta mogą spowodować uszkodzenie samego urządzenia, jak i podłączonych układów elektrycznych.
- Eksploatacja i montaż urządzenia jest dozwolona wyłącznie z uwzględnieniem warunków zawartych w instrukcji i innych dokumentach dotyczących produktu.
- Przed przystąpieniem do pracy należy odłączyć zasilanie urządzenia.

Wymiary






www.vcx.com.pl

DATA SHEET

WESA LC 50 - QUADRUPLE FRAME



Quadruple frame – designed for mounting four sockets and switches in a vertical arrangement vertical and horizontal.

Labeling and packaging

Catalog number	Series	Product name	Unit packaging	EAN code	bulk package	EAN code
LC 50	LC	QUADRUPLE FRAME	1 pcs	05906874479360	10 pcs	05906874479551

Safety information:

- Installation, maintenance and possible replacement of this appliance must only be carried out by a qualified and authorised person.
- All relevant local, regional and national regulations must be complied with when installing, using, maintaining and replacing the unit.
- Opening or otherwise tampering with the unit will void the warranty.
- Loads exceeding the values specified from the manufacturer may damage the device itself as well as the connected electrical systems.
- Operation and assembly of the device is only permitted in accordance with the conditions contained in the manual and other product documents.
- Disconnect the power supply to the appliance before starting work.

Dimensions

